

PFAS in Air : What's Next?



Presented by: Darlene Hoogenes-Stastny



Who we are

A global leader in testing

ALS provides comprehensive testing solutions to clients in a wide range of industries around the world.

Our values

SAFE

RESILIENT

CURIOUS

COMMITTED

CARING

HONEST

Our brand promise

right solutions. right partner.

Our vision

To be the global leader in the discipline of scientific analysis in pursuit of a better world for all.

Our mission

To help our clients leverage the power of testing and data-driven insights for a safer and healthier world.

Our purpose

To help make the world a better place through science, assurance, and sustainability.

Countries

70+

Locations

450+

Staff worldwide

22k+

Revenue (AUD)

2.9b+




Outline




- **Where** are PFAS Compounds in Air?
- **Why** are we concerned about them?
- **When** might PFAS air testing be considered?
- **How** do we sample and analyze for them?
- **What's Next?**



Where: The Sources



Why : Environmental and Health Implications






When: Air Monitoring for Survey or Control

- **Stack/source sampling**
- Canister collection
- GC-MS/MS
- 30 compounds (mostly PID)

- **Ambient sampling**
- ASTM D8591 - TD tubes
- OTM-55 - PUF/XAD traps solvent elution
- GC-MS/MS or LC-MS/MS
- FTOH, sulfonamides and others



Not many known compounds in this category


- **Stack/source sampling**
- Sampling train collection
- LC-MS/MS
- 49 compounds (typical water analytes)

Source: US EPA



How: OTM-45 (Polar Semi-Volatile)



- **Stack sampling**
- Analysis by LC-MS/MS
- 49 compounds (typical water analytes)



What: OTM-50 (Non-polar Volatile)



- **Canister sample collection**
- Analysis by GC-MS/MS
- 30 compounds (mostly PIC/PID)

Volatile fluorinated compounds (VFCs)

- Products of incomplete combustion / destruction (PICs/PIDs)
- Fluorinated refrigerants
- Industrial compounds of interest

Some refrigerants and industrial chemicals are formed from PFAS during destruction.

Shields et al. ACS EST Eng. 2023, 3, 1308–1317.

How? Evacuated Canisters, GC-MS/MS and a BIG Autosampler

Sampling Times : 4,10, 20 or 60 minutes



1.4L Silonite canister
Dedicated PFAS canisters

Passivated silicon ceramic lined stainless-steel



Agilent 7010D GC-MS/MS
Entech 7200-PFAS pre-concentrator and SK-75 autosampler

Quality Control – Field




Considerations

- ✓ Sampling Configuration:
 - moisture and acid gases – configuration varies.
 - duplicate samples – precision or varied volumes?
- ✓ Check system background before & after
- ✓ Pre-heat / flush sampling lines – 2hrs!

Good to know

- Based on TO-15A
- Particulate matter filter required upstream
- Bypass vacuum pump required downstream

OTM-50 FAQ sheet available from US EPA website: Google it or ask us!



Quality Control – Laboratory



Segregation of PFAS
Canisters



PFA Tubing?
fluoropolymer!



Cleaning & Proofing




Shipping



Handling in the lab

OTM-50 – Sampling Tubing Investigation



Sampling Tubing NOT pre-conditioned!

What else? We are Clean Freaks!



Canister Cleaning Procedure - Specific to PFAS


- 1.4 L Silonite canisters are cleaned for 1 week:
 - Heated and purged with clean humidified air, evacuated to 0.0067 kPa.
- Quick Connects cleaned for one week:
 - Rinsed in methanol and water, then heated (100 °C max) under vacuum.
- Flow controllers cleaned, conditioned & checked (digital flow meter) to confirm accuracy
- All canisters are individually proofed; however, we only report 1 per batch on C of As.
 - meets batch proofing requirements, but we actually proof all cans

***By individually proofing each canister, you are able to request individual proof certificates (\$100)
after analysis based on data received.***


- This saves \$\$ as you can pick which, if any, individual canister proofs you want.




OTM-50 Ambient Air Sampling – Lab & Rush Hour Traffic Air



OTM-50 Ambient Air Sampling – Source Identification




OTM-50 Results vs Global Monitoring



Global data reference: Cong et al. 2024 Science of the Total Environment, 956, 177348.

OTM-50 Ambient Air Comparison



GC-MS/MS Method Reporting Limits



Parameter	Synonym	OTM50 QRL (3xMDL)	ALS LOR
		----- ppbv -----	
Tetrafluoromethane	(FC-14)	0.090	0.002
Hexafluoroethane	(FC-116)	0.037	0.002
Chlorotrifluoromethane	(CFC-13)	0.037	0.002
Tetrafluoroethene	C2F4	0.033	0.002
Trifluoromethane	(HFC-23)	0.150	0.002
Difluoromethane	(HFC-32)	0.048	0.002
Octafluoropropane	(PFC-218)	0.037	0.002
Fluoromethane	(HFC-41)	0.057	0.002
1,1,1,2,2-Pentafluoroethane	(HFC-125)	0.037	0.002
1,1,1-Trifluoroethane	(HFC-143a)	0.096	0.002
Hexafluoropropene	C3F6	0.037	0.002
Chlorodifluoromethane	(HCFC-22)	0.033	0.002
Hexafluoropropylene oxide	HFPO	0.063	0.002
1,1,1,2-Tetrafluoroethane	(HFC-134a)	0.048	0.002
Octafluorocyclobutane	(PFC-C318)	0.037	0.002
Decafluorobutane	C4F10	0.037	0.002

Parameter	Synonym	OTM50 QRL (3xMDL)	ALS LOR
		----- ppbv -----	
1H-Heptafluoropropane	C3HF7	0.042	0.002
Trichlorofluoromethane	(CFC-11)	0.042	0.002
Dodecafluoropentane	C5F12	0.069	0.002
Octafluorocyclopentene	(PFC-C1418)	0.037	0.002
1H-Nonafluorobutane	C4HF9	0.033	0.002
Tetradecafluorohexane	C6F14	0.048	0.002
1H-Perfluoropentane	C5HF11	0.048	0.002
Heptafluoropropyl-1,1,1,2-tetrafluoroethyl ether	E1	0.042	0.002
Hexadecafluoroheptane	C7F16	0.037	0.002
1H-Perfluorohexane	C6HF13	0.048	0.002
Octadecafluorooctane	C8F18	0.037	0.002
1H-Perfluoroheptane	C7HF15	0.033	0.002
2H-Perfluoro-5methyl-3-6,dioxanonane	E2	0.037	0.002
1H-Perfluorooctane	C8HF17	0.037	0.002

- ALS Limits of Reporting (LOR) are higher than our statistically derived LOQ for each compound.



Looking to the future...PFAS in Air – Where are we at?

- EPA OTM-50 is up and running in Waterloo, ALS Roll Out completed November 2025.
 - Accredited February 2026
 - Serving North America and the world - canisters are easy to ship.
- EPA OTM-45 roll out in Australia is nearing completion.
- Looking forward to partnering with destruction technology developers.
- **Next:** Moving on to the next quadrant!
 - Method development for non-polar PFAS in ambient air and soil vapour by canister and/or thermal desorption tube.

Questions?



Contacts for PFAS in Air:

Darlene Hoogenes-Stastny

National Air Quality Specialist, Environmental Canada

darlene.stastny@alsglobal.com, tel. 519-719-4201

Tammy Chartrand

National PFAS Program Lead, Environmental Canada

Tammy.chartrand@alsglobal.com, tel. 613-762-6966

acknowledgement :

Andrea Armstrong -Air Quality Manager, ALS Waterloo, ON

Sylvia Fisher –Air Quality Technical Specialist, ALS Waterloo, ON

Heather Lord- Global PFAS Practice Lead